



DISPOSABLE UNCORDED EARPLUGS

DP1000 Series

ANSI/ASA S3.19-1974 | CE/UKCA EN 352:2020

NRR 32dB | SNR 38dB

Disposable uncorded earplugs expand to fit ear canal // Closed cell foam earplugs are resistant to dirt build up

● DP1000 Hi-Vis Orange

Earplug Breakdown

Reusable: No
Metal Detectable: No
Size: One size fits most
Plug Material: Foam
Plug Dimensions: 2.6 x 1.2 cm
Plug Shape: Tapered

⚠ WARNING: Cancer and Reproductive Harm –P65Warnings.ca.gov

Packaging

DP1000 - Sold Individually | 200 per box | 10 boxes per case

PYDP1000 - Sold in pack of 5 | 50 per box | 200 boxes per case

PYDP1000BN - 100 per bin | 3 bins per box | 6 boxes per case

PYDP1000PC - Sold by dozen | 1 per box | 18 boxes per case

Product Guidelines

The level of noise entering a person's ear, when hearing protection is worn as directed is closely approximated by the difference between the A-weighted environmental level and the NRR.

Example: 1. The environmental noise level at the ear is 92 dB(A).

2. The NRR is 26 decibels (dB).

3. The level of noise entering the ear is approximately equal to 60 dB(A).

CAUTION: For noise environments dominated by frequencies below 500 Hz, the C-weighted environmental noise level should be used. Improper fit of this device will reduce its effectiveness in attenuating noise. Plugs should be inserted with a gentle rocking; twisting motion while opposite hand is opening ear canal by pulling the top of ear. Although hearing protectors can be recommended for protection against the harmful effects of impulse noise, the Noise Reduction Rating (NRR) is based on the attenuation noise and may not be an accurate indicator of the protection attainable against impulsive noise, such as gunfire.

i All hearing protection meets ANSI/ASA S3.19-1974 standards. Some options meet European (CE/UKCA EN-352:2002) standards. For more information visit our website or contact your sales representative.



DP1000



PYDP1000PC



PYDP1000



PYDP1000BN



PD500

i PD500 dispenser also available. Holds 500 DP1000 earplugs and can be refilled with PD500R.